

**K40****DEFUSER**

## Operating Instructions

### Initial Start-up Sequence

The Laser DefuserPlus is designed to turn on with your vehicle's ignition. When the vehicle is first started, the Laser DefuserPlus will go through an initial wake-up sequence to let you know the unit is operating properly. This will be indicated by the red laser warning light illuminating for a few seconds and brief audible alerts.

### Alert Notification

The Laser DefuserPlus will notify the driver immediately upon receiving a laser speed measuring gun signal by illuminating the red laser warning light and emitting an urgent high pitched chirp. The laser alert sequence will continue for the duration of the incoming laser gun signal.

### Responding to the Alert

When the alert light and speaker on your Laser DefuserPlus alarms, your immediate attention will be required. Verify your current speed and if necessary take actions to safely reduce your speed.