

# RLS2 QUICK REFERENCE GUIDE

## Menu / Customizable Settings

- **Press and hold DIM / MENU button** for 3 seconds. The voice will announce, "Menu," and the display will read **\*MENU\***.
- **Press and release DIM / MENU button** to scroll through the preferences until you reach the option to be changed.
- To change setting, **press and release  $\wedge$  or  $\vee$  button**. Both the display and voice will announce the change.
- **Press and release DIM / MENU button** to continue scrolling to another preference.

Menu Options <i>(in order displayed)</i>		Default Setting	Description
1	Voice Type	Female	Choose male or female voice for audio alerts.
2	Audible Voice	On	For all initial audio alerts: "Voice On" uses voice; "Voice Off" uses tones only.
3	Wake-Up	Wake-Up Long	"Wake-Up Long" is a standard 5-second sequence. "Wake-Up Short" uses an abbreviated sequence.
4	Speed Displayed	On	"Speed On" displays current speed in mph / kph when driving over 5 mph / kph. "Speed Off" turns off this display.
5	Compass Heading	On	Displays current compass heading when driving over 5 mph / kph.
6	Traffic Sensor Filter	Off	Enables filtration of K-Band radar signals from traffic flow sensors.
7	mph / kph	mph	Choose mph or kph.
8	Automute	Off	Automatically reduces volume by 50% after 5 seconds.
9	X-Band	On	Enables the detection of X-Band radar.
10	K-Band	On	Enables the detection of K-Band radar.
11	Ka-Band	On	Enables the detection of Ka-Band radar.
12	Laser	On	Enables the detection of laser.
13	Mute Locations	N/A	Clears all stored muted locations. See Pg. 12
14	Alert Locations	N/A	Clears all stored alert locations. See Pg. 13
15	Factory Reset	RESET	Original factory default for all settings.

# RLS2 QUICK REFERENCE GUIDE

## Frequently Used Features & Functions

### **Mute Audio Before or During Alert** (Owner's Manual pgs.13-14)

<b>30-second Mute</b>	<b>Press and release MUTE button.</b>
<b>5-minute Mute</b>	<b>Press and hold MUTE button for 3 seconds.</b>

### **Mark to Mute\*** (Owner's Manual pg. 12)

<b>Mute location</b>	<b>Press and release MARK button</b> when you want to mark a location for mute.
<b>Remove a muted location</b>	<b>Press and release MARK button</b> in muted location. Voice confirms removal.

\*A radar or laser signal must be present in order to mark a location for mute.

### **Mark to Alert** (Owner's Manual pg. 13)

<b>Mark location</b>	<b>Press and hold MARK button</b> when you want to mark a location for alert.
<b>Remove a marked location</b>	<b>Press and hold MARK button</b> in marked location. Voice confirms removal.

**To remove all marked MUTE and ALERT locations, see pgs. 12-13 in Owner's Manual.**

### **Activating / Adjusting Quiet Ride** (Owner's Manual pg. 9)

- **Press and release QUIET RIDE button** to activate the Quiet Ride menu. Voice will announce the current setting.
- Use **^ or v buttons** to adjust the speed settings on Quiet Ride. Any selected speed setting indicates Quiet Ride is on.
- When you have made your desired Quiet Ride speed selection, stop scrolling and voice will announce, "Quiet Ride Set."